




Software Upgrade


ZoneVu

ZVK-77 Keyboard

This document details the procedure for upgrading equipment firmware/software.



1. Remove Power
2. Remove screw indicated in the diagram above
3. Lift the back off and disconnect cables as required noting where they connected to.
4. Locate the chip indicated below:



5. Remove Chip
6. Replace with new chip
7. Reconnect any disconnected cables
8. Replace lid
9. Power up and confirm upgrade

MEYERTECH

OFFICE BLOCK ONE
SOUTH LINK BUSINESS PARK
OLDHAM OL4 1DE

TEL +44 (0) 161 628 8406
FAX +44 (0) 161 628 9811
Email sales@meyertech.co.uk
<http://www.meyertech.co.uk>